

Final Deliverables: Source Code

Date	18 November 2022
Team ID	PNT2022TMID53114
Project Name	VirtualEye - Lifeguard for swimming pools to detect active drowning

App.py

```
from cloudant.client import Cloudant
import numpy as np
import os
from flask import Flask, app,request,render_template
from tensorflow.keras import models
from tensorflow.keras.models import load_model
from tensorflow.keras.preprocessing import image
from tensorflow.python.ops.gen_array_ops import concat
from tensorflow.keras.applications.inception_v3 import preprocess_input
import cvlib as cv
from cvlib.object_detection import draw_bbox
import cv2
import time
import numpy as np
from playsound import playsound
#import requests
from flask import Flask, request, render_template, redirect, url_for
#Loading the model

# Authenticate using an IAM API key
client =
Cloudant.iam('06e7c9cd-cbb3-4b56-a40a-e669cf5b0906-bluemix','VPbZAA_fmWRYpJdz4kowa
ZwERWNd4vqCSvOzVI5DXmNn', connect=True)

# Create a database using an initialized client
my_database = client['database1']

app = Flask(__name__)

@app.route("/")
def index():
```

```
return render_template("./login.html")
```

```
@app.route("/about")
def about():
    return render_template("./about.html")
```

```
@app.route("/demo")
def demo():
    return render_template("./demo.html")
```

```
@app.route("/logout")
def logout():
    return render_template("./logout.html")
```

```
@app.route("/register")
def register():
    return render_template("./register.html")
```

```
@app.route("/result")
def res():
    webcam = cv2.VideoCapture('drowning7.mp4')
    if not webcam.isOpened():
        print("Could not open webcam")
        exit()
```

```
t0 = time.time() #gives time in seconds after 1970
#variable dcount stands for how many seconds the person has been standing still for
centre0 = np.zeros(2)
isDrowning = False
```

```
#this loop happens approximately every 1 second, so if a person doesn't move,
#or moves very little for 10seconds, we can say they are drowning
#loop through frames
```

```
t0 = time.time() #gives time in seconds after 1970
```

```
#variable dcount stands for how many seconds the person has been standing still for
centre0 = np.zeros(2)
isDrowning = False
```

```
#this loop happens approximately every 1 second, so if a person doesn't move,
```

#or moves very little for 10seconds, we can say they are drowning

#loop through frames

while webcam.isOpened():

read frame from webcam

status, frame = webcam.read()

if not status:

print("Could not read frame")

exit()

apply object detection

bbox, label, conf = cv.detect_common_objects(frame)

#simplifying for only 1 person

#s = (len(bbox), 2)

print(bbox)

if(len(bbox)>0):

bbox0 = bbox[0]

#centre = np.zeros(s)

centre = [0,0]

#for i in range(0, len(bbox)):

#centre[i] = [(bbox[i][0]+bbox[i][2])/2, (bbox[i][1]+bbox[i][3])/2]

centre = [(bbox0[0]+bbox0[2])/2, (bbox0[1]+bbox0[3])/2]

#make vertical and horizontal movement variables

hmov = abs(centre[0]-centre0[0])

vmov = abs(centre[1]-centre0[1])

#there is still need to tweek the threshold

#this threshold is for checking how much the centre has moved

x=time.time()

threshold = 30

if(hmov>threshold or vmov>threshold):

print(x-t0, 's')

t0 = time.time()

isDrowning = False

else:

```
print(x-t0, 's')
if((time.time() - t0) > 5):
    isDrowning = True
```

```
#print('bounding box: ', bbox, 'label: ' label , 'confidence: ' conf[0], 'centre: ', centre)
#print(bbox,label ,conf, centre)
print('bbox: ', bbox, 'centre:', centre, 'centre0:', centre0)
print('Is he drowning: ', isDrowning)
```

```
centre0 = centre
# draw bounding box over detected objects
```

```
out = draw_bbox(frame, bbox, label, conf,isDrowning)
```

```
#print('Seconds since last epoch: ', time.time()-t0)
```

```
# display output
cv2.imshow("Real-time object detection", out)
print(isDrowning)
if(isDrowning == True):
```

```
    playsound('alarm.mp3')
```

```
# press "Q" to stop
if cv2.waitKey(1) & 0xFF == ord('q'):
    break
```

```
# release resources
webcam.release()
cv2.destroyAllWindows()
```

```
@app.route('/afterreg', methods=['GET'])
def afterreg():
    username = request.args.get('uname')
    password = request.args.get('password')
    print(list(request.form.values()))
    data = {
```

```

'uname': username,
'password': password
}
print(data)
query = {'uname': {'$eq': data['uname']}}
docs = my_database.get_query_result(query)
print(docs)

print(len(docs.all()))

if(len(docs.all())==0):
    url = my_database.create_document(data)
    #response = requests.get(url)
    return render_template('login.html', pred="Registration Successful, please login using your
details")
else:
    return render_template('login.html', pred="You are already a member, please login using
your details")

@app.route('/afterlogin',methods=['GET'])
def afterlogin():
    user = request.args.get('uname')
    passw = request.args.get('password')
    print(user + passw)
    query = {'uname': {'$eq': user}}
    docs = my_database.get_query_result(query)
    print(docs)
    print(len(docs.all()))
    if(len(docs.all())==0):
        return render_template('login.html', pred="The username is not found.")
    else:
        if((user==docs[0][0]['uname'] and passw==docs[0][0]['password'])):
            return render_template('about.html')
        else:
            return render_template('login.html', pred="incorrect password, please try again.")

if __name__ == '__main__':
    app.run()

```

Object_detection.py

```
#import necessary packages
import cv2
import os
import numpy as np
from .utils import download_file

initialize = True
net = None
dest_dir = os.path.expanduser('~') + os.path.sep + '.cvlib' + os.path.sep + 'object_detection' +
os.path.sep + 'yolo' + os.path.sep + 'yolov3'
classes = None
#colors are BGR instead of RGB in python
COLORS = [0,0,255], [255,0,0]

def populate_class_labels():

    #we are using a pre existent classifier which is more reliable and more efficient than one
    #we could make using only a laptop
    #The classifier should be downloaded automatically when you run this script
    class_file_name = 'yolov3_classes.txt'
    class_file_abs_path = dest_dir + os.path.sep + class_file_name
    url = 'https://github.com/Nico31415/Drowning-Detector/raw/master/yolov3.txt'
    if not os.path.exists(class_file_abs_path):
        download_file(url=url, file_name=class_file_name, dest_dir=dest_dir)
    f = open(class_file_abs_path, 'r')
    classes = [line.strip() for line in f.readlines()]

    return classes

def get_output_layers(net):

    #the number of output layers in a neural network is the number of possible
    #things the network can detect, such as a person, a dog, a tie, a phone...
    layer_names = net.getLayerNames()

    output_layers = [layer_names[i - 1] for i in net.getUnconnectedOutLayers()]

    return output_layers

def draw_bbox(img, bbox, labels, confidence, Drowning, write_conf=False):
```

```

global COLORS
global classes

if classes is None:
    classes = populate_class_labels()

for i, label in enumerate(labels):

    #if the person is drowning, the box will be drawn red instead of blue
    if label == 'person' and Drowning:
        color = COLORS[0]
        label = 'DROWNING'
    else:
        color = COLORS[1]

    if write_conf:
        label += ' ' + str(format(confidence[i] * 100, '.2f')) + '%'

    #you only need to points (the opposite corners) to draw a rectangle. These points
    #are stored in the variable bbox
    cv2.rectangle(img, (bbox[i][0],bbox[i][1]), (bbox[i][2],bbox[i][3]), color, 2)

    cv2.putText(img, label, (bbox[i][0],bbox[i][1]-10), cv2.FONT_HERSHEY_SIMPLEX, 0.5,
color, 2)

return img

def detect_common_objects(image, confidence=0.5, nms_thresh=0.3):

    Height, Width = image.shape[:2]
    scale = 0.00392

    global classes
    global dest_dir

    #all the weights and the neural network algorithm are already preconfigured
    #as we are using YOLO

    #this part of the script just downloads the YOLO files
    config_file_name = 'yolov3.cfg'
    config_file_abs_path = dest_dir + os.path.sep + config_file_name

```

```

weights_file_name = 'yolov3.weights'
weights_file_abs_path = dest_dir + os.path.sep + weights_file_name

url = 'https://github.com/Nico31415/Drowning-Detector/raw/master/yolov3.cfg'

if not os.path.exists(config_file_abs_path):
    download_file(url=url, file_name=config_file_name, dest_dir=dest_dir)

url = 'https://pjreddie.com/media/files/yolov3.weights'

if not os.path.exists(weights_file_abs_path):
    download_file(url=url, file_name=weights_file_name, dest_dir=dest_dir)


global initialize
global net

if initialize:
    classes = populate_class_labels()
    net = cv2.dnn.readNet(weights_file_abs_path, config_file_abs_path)
    initialize = False

blob = cv2.dnn.blobFromImage(image, scale, (416,416), (0,0,0), True, crop=False)

net.setInput(blob)

outs = net.forward(get_output_layers(net))

class_ids = []
confidences = []
boxes = []

for out in outs:
    for detection in out:
        scores = detection[5:]
        class_id = np.argmax(scores)
        max_conf = scores[class_id]
        if max_conf > confidence:
            center_x = int(detection[0] * Width)
            center_y = int(detection[1] * Height)
            w = int(detection[2] * Width)
            h = int(detection[3] * Height)
            x = center_x - w / 2

```



```
y = center_y - h / 2
class_ids.append(class_id)
confidences.append(float(max_conf))
boxes.append([x, y, w, h])
```

```
indices = cv2.dnn.NMSBoxes(boxes, confidences, confidence, nms_thresh)
```

```
bbox = []
label = []
conf = []
```

```
for i in indices:
```

```
    i = i
    box = boxes[i]
    x = box[0]
    y = box[1]
    w = box[2]
    h = box[3]
    bbox.append([round(x), round(y), round(x+w), round(y+h)])
    label.append(str(classes[class_ids[i]]))
    conf.append(confidences[i])
```

```
return bbox, label, conf
```